

Min. 100mm

Min. 100mm

A (1 : 2,5)

B (1 : 1)

- Side wall
- Glue as for Autoproducts L-Floor
- 3P Rail
Length: Minimum 674 mm
- Minimum 4 pieces countersunk drilling screws Ø5.5x25,
(ISO 15842 or similar)
Minimum distance: 101.6mm
Longer screws can be used depending on headliner.
- Rivets
(see note)
- Rivets
(see note)
- Glue as for Autoproducts L-Floor
- Headliner (or interlayer to allow correct mounting of countersunk screws)
- Wall airline rail (ISO 7166-1985)
Length: Minimum 127 mm
- Airline stud (ISO 7166-1985)
(Using minimum 3 holes)
- 7/16 UNF Bolt or similar
- Optional element
- Safety belt anchorage

Note:
Rivets, optional blind rivets,
optional self drilling screws
(only for correct positioning until
adhesive is sufficiently hardened)


Principal drawing.
Body of Mercedes-Benz Sprinter shown.
For mounting of 3P-rail, see vehicle-specific drawing.

REVISION HISTORY

Rev	Date	Designer	Description
02	28-6-2023	NPTK	Headliner added, text designation changed for some elements
03	26-10-2023	NPTK	Larger screws Ø6.3, minimum distance added and other changes



Autoproducts ApS
Baggeskærvej 48
DK-7400 Herning
 Phone: +45 8818 1703



Creation date: 12-02-2023
 Revision date: 26-10-2023
 Draughtman: NPTK
 Designer: NPTK
 Scale: 1 : 12
 Page no.: 1/1

Drawing no.: Wheelchair fixation -R03